



HDL-MPAC01.48

iElegance Series Air Condition Control Panel


# buspro

#### Datasheet

Issued: April 7, 2019 Edition V1.0.0



Figure 1. iElegance Series Air Condition Control Panel






Figure 2. Dimensions - Front View Figure 3. Dimensions - Side View




Figure 4. Back View




Figure 5. Front View

#### Overview

iElegance Series Air Condition Control Panel (See Figure 1) is compliant with the hotel control system, which offers a convenient way for the users to control AC.

## **Functions**

- Controls the room temperature by setting the fan speed, mode and on/off of AC.
- AC Modes: cooling, heating, ventilation, auto.
- Speed control: High, Mid, Low, Auto.
- Temperature display and AC status display
- Communication: HDL Buspro.
- Supports online update via HDL Buspro.

## **Important Notes**

- The panel should be installed on the wall box.
- Buspro cable CAT5E or dedicated HDL Buspro cable.
- It is recommended to adopt Buspro connection Series connection (hand-in-hand recommended).

### **Product Information**

Dimensions - See Figure 2 - 3

Back view - See Figure 4

Front view - See Figure 5

- 1. Working mode
- 2. Fan speed
- 3. Speed control and AC on/off button
- 4. Set lower temperature
- 5. Real-time temperature
- 6. LCD Display
- 7. Mode control button
- 8. Set higher temperature

Temperature Setting range: 0 - 30°C

Speed control and AC on/off Button: [off, auto, high, medium, low] as a loop

Mode Control Button: [Auto, cooling, heating, fan] as a loop

#### Product installation and disassembly

#### Installation - See Figure 6 - 8

- Step 1. Install the wall box in the wall.
- Step 2. Fix the base panel into the wall box with screws.
- Step 3. Install the cover on the power interface. Make sure the base panel is connected with the panel cover tightly.

## Disassembly - See Figure 9

- Step 1. Insert the panel gap with a slotted screwdriver.
- Step 2. Pry up the panel cover gently and take down the panel.

## **Safety Precautions**



- The installation and commissioning of the device must be carried out by HDL or the organization designated by HDL. For planning and construction of electric installations, the relevant guidelines, regulations and standards of the respective country are to be considered.
- The device should be installed in wall box. HDL does not take responsibility for all the consequences caused by installation and wire connection that are not in accordance with this document.
- Please do not privately disassemble the device or change components, otherwise it may cause mechanical failure, electric shock, fire or body injury.
- Please resort to our customer service department or designated agencies for maintenance service.

  The warranty is not applicable for the product fault caused by private disassembly.

#### **Package Contents**

HDL-MPAC01.48\*1 / Screw\* 2 / Datasheet\*1




Figure 6 – 8. Installation




Figure 9. Disassembly

#### **Technical support**

E-mail: support@hdlautomation.com Website: https://www.hdlautomation.com

©Copyright by HDL Automation Co., Ltd. All rights reserved. Specifications subject to change without notice.

## abalaal Data

Technical Data					
Basic Parameters					
Working voltage	12~30V DC				
Working current	25mA/24V DC				
Communication	HDL Buspro				
Cable diameter of Buspro terminal	0.6-0.8mm				
External Environment					
Working temperature	-5°C~45°C				
Working relative humidity	≤90%				
Storage temperature	-20°C~60°C				
Storage relative humidity	≤93%				
Specifications					
Dimensions	86×86×22 (mm)				
Net weight	97g				
Housing material	ABS, Aluminum				
Installation	Wall box (See Figure 6 - 8)				
Protection rating (Compliant with EN 60529)	IP20				

#### Name and Content of Hazardous Substances in Products

	Hazardous substances					
Components	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Chromium VI (Cr (VI))	Poly- brominated biphenyls (PBB)	Poly- brominated diphenyl ethers ( PBDE )
Plastic	0	0	0	0	O	0
Hardware	0	0	0	0	-	-
Screw	0	0	0	×	-	-
Solder	×	0	0	0	-	-
PCB	×	0	0	0	O	0
IC	0	0	0	0	×	×

The symbol "-" indicates that the hazardous substance is not contained.

The symbol "o" indicates that the content of the hazardous substances in all the homogeneous materials of the component is below the limit requirement specified in the Standard IEC62321-2015.

The symbol "x" indicates that the content of the hazardous substance in at least one of the homogeneous materials of the part exceeds the limit requirement specified in the Standard IEC62321-2015.

# **HDL Buspro Cable Guide**

HDL Buspro	HDL Buspro Cable	CAT5/CAT5E	
DATA+	Yellow	Blue/Green	
DATA-	White	Blue white/Green white	
СОМ	Black	Brown white/Orange white	
24V DC	Red	Brown/Orange	